

# **Identifying Unknown Ferrites With an Antenna Analyzer**

[w6nbc.com/slides.html](http://w6nbc.com/slides.html)

# A LITTLE FUN

Something – Once you see it –  
you never forget

E.g. Dots in the movie theater  
Movie cue marks



**Movie  
Cue  
Mark**

I Pledge Allegiance  
to the Flag  
of the  
United States  
of America







*...and to the  
Republic  
Forwhicitstan*



# *Toroid Baluns Largely a Mystery*

**Most hams don't know  
how to design with a  
ferrite toroids  
Especially from  
UNKNOWN Cores**





# Snap-On's



# Toroids







**Vicky**

**Carl**

**AE9YL**

**K9LA**

**Leutzelschwab**

**Based on his article  
“Name That Core”**



## Name That Core

Carl Luetzelschwab K9LA

If you've been active in Amateur Radio for a number of years, perhaps you've accumulated a junk box full of components. These components could be resistors, transistors, tubes (I still have some of these!), capacitors, inductors, knobs, meters, cores, connectors, etc.

Of those components, it's likely that the characteristics of most of them are identified by a color code (resistors, for example), by performing a mathematical calculation (air-wound inductors, for example), by reading labeling (transistors, for example) or by doing a visual inspection (connectors, for example). The one exception seems to be cores – generally ferrite cores have no marking to identify their characteristics (there are iron powder cores that are color coded – more on this later).

A great example of 'no marking' is a box full of half-cores that I have. The idea here is to put a wire or cable in one of these half-cores and then add another half-core to fully encase the wire or cable. But I have no idea what these cores are. One way to answer the 'what are they?' question is to stick a short wire through the core and measure the resulting impedance – its series resistance  $R_s$  and its series reactance  $X_s$ . You can easily do this with an MFJ-259B (HF/VHF SWR analyzer) or something similar with one end of the wire to the center conductor of the RF connector and the other end to the ground side of the RF connector.

[w6nbc.com/slides.html](http://w6nbc.com/slides.html)






FT-240-61

MFJ-  
259D


# Procedure

- On the Home Screen
- Pick a Frequency Band
- TUNE knob → top or bottom
- **Tune up/down until  $R = X$**   
Change bands if you can't
- Note the Frequency **27.844**
- Refer to his Permeability Chart for the Mix





# Ferrite Characteristics





**Comet  
CAA-500**

**MFJ-259  
All models**



**Rig Expert**

**NanoVNA**



Now that you have:  
The MIX and SIZE  
of the core



# A MUST HAVE Free On-Line Calculator

[https://coil32.net/onlie-  
calculators/amidon-ferrite- torroid-  
calculator.html](https://coil32.net/onlie-calculators/amidon-ferrite-torroid-calculator.html)

[w6nbc.com/slides.html](http://w6nbc.com/slides.html)

<https://coil32.net/online-calculators/amidon-ferrite-torroid-calculator.html>

SELECT THE TOROID:

Material type of the toroid –

Dimension type of the toroid –

**Available information about the toroid:**

Initial magnetic permeability ( $\mu$ ): 850

Saturation flux density ( $B_s$ ): 2950 Gs

Residual flux density ( $B_r$ ): 1310 Gs

Coercive Force ( $H_c$ ): 0.45 Oe

Curie Temperature: 135 °C

Dimensions (OD x ID x H): 35.6 x 12.7

$A_L$  factor: 885 nH/N<sup>2</sup>

ENTER THE INPUT DATA:


$L =$    – Required inductance

Calculate

RESULT:


$N =$   – Number of turns

THREE  
INPUTS  
(STEPS)




Results

**E.G. FT-240-43**



**Power**

**Only two size choices**



**FT-240**

**Full Limit**

**Stack of 2**

**FT-140**

**100 Watts**



RF resistance = **200  $\Omega$  min.**  
4 times coax impedance 50  $\Omega$

**RF Resistance**  $X_L = 2\pi f L$

$$L_{\mu H} = \frac{200 \Omega}{6.28 \times f_{MHz}}$$



*No More Mystery*

**And you can  
thank Carl  
Leutzelschwab**



**Vicky**

**AE9YL**

**Carl**

**K9LA**

**Leutzelschwab**

**Based on his article  
“Name That Core”**





**w6nbcmail@  
gmail.com**

**w6nbc.com/probe**



**DØGGY**

*"That's all Folks!"*

**w6nbc.com/slides.html**

